




Notice d'utilisation




1. **FR** Tirer, tourner et faire descendre
DE Ziehen, drehen und runterdrücken
GB Pull, turn and depress
ES Estirar, girar y apretar



2. **FR** En position ouverte, maintenez l'anse enfoncée, ensuite composez votre code
DE Runtergedrückt halten und code einstellen
GB Hold down and set new code
ES Mantener presionado hacia abajo e introducir el código



3. **FR** Tourner et faire descendre
DE Drehen und runterdrücken
GB Turn and depress
ES Girar y apretar



4. **FR** Tourner les molettes
DE Zahlenräder verstellen
GB Scramble digits
ES Remover las ruedas